

RAYNOX Camcorder Cross Reference Table for Fisheye Lens

2010/9/7
www.raynox.com

Camera Maker	Camera Model	HD-FXR180 (Diagonal)	DCR-CF187PRO(Circular)	DCR-FE181PRO(Diagonal)	XL-3000PRO(0.3x)	MX-3062PRO(0.3x)	MX-3000PRO(0.3x)	HDP-5072EX(0.5x)	HD-3035PRO(0.3x)
SONY	HDR-FX1000(E)/AX2000(E), HVR-Z5(E)(U), HXR-NX5(E)(U)		RA6272*11					Direct mount	
	HDR-FX7(E), HVR-V1(E)(N)(U)		Direct mount*9	Direct mount*10	Direct mount	Direct mount		RA7262	
	HDR-CX7(E)(K)(K)(KE)/CX6EK								Direct mount
	HDR-UX20								RA3730(Included)
	HDR-UX1								RA3730(Included) *1
	HDR-SR12(E)/SR11(E)/CX12(E)								Direct mount
	HDR-SR8(E),HDR-SR7(E)								Direct mount
	HDR-SR1								RA3730(Included) *1
	HDR-HC3								RA3730(Included) *1
	HVR-Z7(E)/S270(E)								Direct mount
	HDR-FX1/HVR-Z1(U)(E)	Direct mount							Direct mount
	HDR-HC9(E)/HC7(E)/CX7/UX7(E)/HC5(E)/UX5(E)								Direct mount
	HDR-HC1, HVR-A1		RA6252(Included)+RA5237A*8	RA6252(Included)+RA5237A*7					Direct mount
	HDR-CX110/150/155E/116E/115E, HDR-XR150/155E								RA3730(Included)
	HDR-XR100(E)/105(E)/CX100(E)/105(E)								RA3730(Included)
	HDR-CX300/305(E)/350V(E)/XR350V(E)								RA3730(Included)
	HDR-XR500V(E)/520V(E), CX500V(E)/520V(E)								Direct mount
	HDR-CX550V(E)/XR550V(E)								Direct mount
	HXR-MC1								RA3730(Included)
	DCR-DVR508/DCR-DVD908(E)								Direct mount
	DCR-DVD405/403/505								RA3730(Included)
	DCR-DVD308/DCR-DVD708(E)								RA3730(Included)
	DCR-SR300(C)(E)								Direct mount
	DCR-SR62(E)								RA3730(Included)
	DCR-SR100/SR60								RA3730(Included)
	DCR-HC62(E)/DVD810								RA3730(Included)
	DCR-HC96/90								RA3730(Included)
	DCR-HC48								RA3730(Included)
DCR-VX2100/2000/PD-170/PD-150/DSR-250				RA6258(Included)	Direct mount		Direct mount		
DCR-VX1000					Direct mount				
DCR-TRV950/PDX10				RA6252(Included)+RA5237A	RA5237A			Direct mount	
PMW-EX1(E)/EX1R(E)									
Canon	HF11/10/100/HG21								Direct mount
	HF20/21								Direct mount
	HFM30/31/32/36/300/306								Direct mount
	HF S10/11/100						Direct mount		
	HF S20/21/200			RA6258(Included)					
	XH-G1, XH-A1			RA6272					Direct mount
	XL1/XL2/XL H1 16X*20X Zoom								Direct mount
	HV30/HV20/HG10								
	HV10								Direct mount
	HR10								Direct mount
	DM-DC40				RA5237A				Direct mount
	DM-DC20								RA3727P5(Included)
	DM-FV500(ZR 100/MV 790/800/800i)								RA3728P5
	IXY DV M5(Optura 600A/MVX iE)								RA3734P5(Included)
	IXY DV S1(Optura S1/MVX1Si)								RA3727P5(Included)
	IXY DV5(Elura 50/MV 6iMC)/DV3(Elura 40MC/MV5iMC)								RA3728P5
	FV M300(Elura 100/MVX 430/450/460)								RA3727P5(Included)
	FV M1(Optura Xi/MVX3i)					RA5246			
	XV-1(GL1/XM1)/XV-2(GL2/XM2)			RA6258(Included)	Direct mount			Direct mount	
	PV130					RA5243A			

*1:Vignetting occurs at 4:3 Still mode *2:Vignetting occurs at Still/Video/under scanning mode *3:Remove camera's cosmetic ring or hood before attaching the Raynox lens *4:Vignetting occurs at Still/16:9 Video mode when used with QC-303 *5:Vignetting occurs at Still mode *6:Slight vignetting occurs at under scanning/still mode *7:Unable to take a full diagonal fisheye image *8:Unable to take circular fisheye image other than at 4:3 Still mode *9:may not produce either circular or diagonal fish-eye image *10:Slight vignetting may occur in (under scanning) mode and still image mode in maximum wideangle zooming. *11:A Circular Fisheye image can be captured at still mode in under-scanning system(PC monitor).

Remote control function and internal video light/Flash may not work properly with conversion lens attached.

RAYNOX Camcorder Cross Reference Table for Fisheye Lens

2010/9/7
www.raynox.com

Camera Maker	Camera Model	HD-FXR180 (Diagonal)	DCR-CF187PRO(Circular)	DCR-FE181PRO(Diagonal)	XL-3000PRO(0.3x)	MX-3062PRO(0.3x)	MX-3000PRO(0.3x)	HDP-5072EX(0.5x)	HD-3035PRO(0.3x)
Panasonic	HDC-SD1/DX3, AG-HSC1U								RA3743(Included)*6
	HDC-SD9/HS9/SD5/SD5EG/SX5								Direct mount*3
	HDC-SD100/HS100								Direct mount*3
	HDC-TM30								RA37305P5(Included)
	HDC-HS300/350/200, TM300/350/SD200								RA3743(Included) *3
	HDC-SD700/HS700(K)/TM700(K)/SDT750(K)								
	AG-HCK10G								RA3743(included)
	AG-HMC150/151/155, AG-HPX170/175							Direct mount	
	AG-DVX100(A)(AE)(AP)(B)(BE)(BP)							Direct mount	
	AG-HVX200(E)(MC)(P), AG-HVX202EN								
	VDR-D310								Direct mount
	VDR-D400								RA3743(Included)
	VDR-D300/D250					RA5237A			Direct mount
	SDR-S100/S200								Direct mount*3
	NV-GS320								Direct mount
	NV-GS500/400					RA5243A			RA3743(Included)*3
NV-GS300					RA5237A			Direct mount	
NV-GS250					RA5243A			RA3743(Included)*3	
VDR-M30K									
NV-GS55/GS50									
JVC	GZ-HM400								
	GZ-HM550(BEK)								Direct mount
	GZ-HM1(SEK)								
	GZ-HD620								Direct mount
	GZ-HD300/HD320								RA37305P5(Included)
	GZ-HD40/HD30								
	GZ-HD5/HD6								
	GZ-HD3/HD7					RA5246			
	GZ-MG275/MG255								RA37305P5(Included)*5
	GZ-MG575/MG555								
	GZ-MG505								Direct mount*3*4
	GZ-MG77/MG67/MG70/MG50/MG40								RA37305P5(Included)
	GZ-MG47								RA37305P5(Included)
	GR-D650								RA37305P5(Included)
	GR-D350								RA3727P5(Included)
	GR-D250								RA3727P5(Included)
	GZ-MC500					RA5237A			Direct mount
	GZ-MC200/MC100								RA37305P5(Included)
	GR-DV3000/DV3500								
GR-DV5000					Direct mount				
GR-DV900K/DV700K					Direct mount				
GR-DV500					RA5237A				
GR-X5					RA5237A				
HITACHI	DZ-BD10H/10HA								RA3743(Included)*5
	DZ-BD7(H)(HA)(HE), DZ-BD70(A)(E)								RA3743(Included)*5
	DZ-GX3300								Direct mount
	DZ-GX3200								RA3734P5(Included)*3
	DZ-GX3100								RA37305P5(Included)
TOSHIBA	GSC-R60/R30/MEHV10								RA37305P5(Included)

*1:Vignetting occurs at 4:3 Still mode *2:Vignetting occurs at Still/Video/under scanning mode *3:Remove camera's cosmetic ring or hood before attaching the Raynox lens *4:Vignetting occurs at Still/16:9 Video mode when used with QC-303 *5:Vignetting occurs at Still mode *6:Slight vignetting occurs at under scanning/still mode *7:Unable to take a full diagonal fisheye image *8:Unable to take circular fisheye image other than at 4:3 Still mode *9:may not produce either circular or diagonal fish-eye image *10:Slight vignetting may occur in (under scanning) mode and still image mode in maximum wideangle zooming. *11:A Circular Fisheye image can be captured at still mode in under-scanning system(PC monitor).

Remote control function and internal video light/Flash may not work properly with conversion lens attached.