

# RAYNOX Camcorder Cross Reference Table for Macro Lens

2010/9/13  
www.raynox.com

Camera Maker	Camera Model	DCR-150(4.8-diopter)	DCR-250(8-diopter)	MSN-202(25-diopter)	MSN-505(32-diopter)	DCR-5320PRO (5-diopter/3-diopter/2-diopter)
SONY	HDR-FX1000(E)/AX2000(E), HVR-Z5(E)(U), HXR-NX5(E)(U)	RA4372A	RA4372A	RA3772A		Direct mount
	HDR-FX7(E), HVR-V1(U)(E)(N)	UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)	RA7262
	HDR-CX7/CX7KE/CX7EK/CX7E/CX7K/CX6EK	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	HDR-UX20			RA3730	RA3730	
	HDR-UX1			RA3730	RA3730	
	HDR-SR12/SR12E, SR11/SR11E, CX12/CX12E	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	HDR-SR8/SR8E, HDR-SR7/SR7E	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	HDR-SR1			RA3730	RA3730	
	HDR-HC3			RA3730	RA3730	
	HVR-Z7/Z7E/S270/S270E					Direct mount
	HDR-FX1/HVR-Z1/Z1U/Z1E	RA4372A/UAC2000(included)+RA6272	RA4372A/UAC2000(included)+RA6272	RA3772A/UAC3500(included)+RA6272		Direct mount
	HDR-HC9/HC9E/HC7/HC7E/CX7/UX7/UX7E/HC5/HC5E/UX5/UX5E	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	HDR-HC1/HVR-A1	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	HDR-CX110/150/155E/116E/115E, HDR-XR150/155E			RA3730	RA3730	
	HDR-XR100(E)/105(E)/, HDR-CX100(E)/105(E)	RA4337A+RA3730	RA4337A+RA3730	RA3730	RA3730	
	HDR-CX300/305E/350V(E)/XR350V(E)	RA4337A+RA3730	RA4337A+RA3730	RA3730	RA3730	
	HDR-XR500(V)(VE)/520(V)(VE)	RA4337A	RA4337A	Direct mount	Direct mount	
	HDR-CX550V(E)/XR550V(E)	RA4337A	RA4337A	Direct mount	Direct mount	
	HXR-MC1					
	DCR-DVR508/DCR-DVD908/908E	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	DCR-DVD405/403/505			RA3730	RA3730	
	DCR-DVD308/DCR-DVD708/708E			RA3730	RA3730	
	DCR-SR300/300C/300E	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	DCR-SR62/62E			RA3730	RA3730	
	DCR-SR100/SR60			RA3730	RA3730	
	DCR-HC62/HC62E/DVD810			RA3730	RA3730	
	DCR-HC96/90			RA3730	RA3730	
	DCR-HC48			RA3730	RA3730	
	DCR-VX2100/2000/PD-170/PD-150/DSR-250	UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)	
	DCR-VX1000	UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)	
	DCR-TRV950/PDX10	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
	PMW-EX1(E)/EX1R(E)					RA7277
	Canon	HF11/10/100/HG21			Direct mount	Direct mount
HF20/21		RA4337A	RA4337A	Direct mount	Direct mount	
HF M31/32/36/306		RA4337A	RA4337A	Direct mount	Direct mount	
HF S10/11/100		UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)	
HF S20/21/200		UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)	
XH-G1/XH-A1		RA4372A/UAC2000(included)+RA6272	RA4372A/UAC2000(included)+RA6272	RA3772A/UAC3500(included)+RA6272	RA3772A/UAC3500(included)+RA6272	Direct mount
XL1/XL2/XL H1 16X·20X Zoom		RA4372A/UAC2000(included)+RA6272	RA4372A/UAC2000(included)+RA6272	RA3772A/UAC3500(included)+RA6272	RA3772A/UAC3500(included)+RA6272	Direct mount
HV30/HV20/HG10		Direct mount	Direct mount	UAC3500(Included)+RA5243B	UAC3500(Included)+RA5243B	
HV10		UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
HR10		UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
DM-DC40		UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount	
DM-DC20				RA3727P5	RA3727P5	
DM-FV500(ZR 100/MV 790/800/800i)				RA3728P5	RA3728P5	
IXY DV M5(Optura 600A/MVX 1E)				RA3734P5	RA3734P5	
IXY DV S1(Optura S1/MVX1S1)				RA3727P5	RA3727P5	
IXY DV5(Elura 50/MV 6iMC)/DV3(Elura 40MC/MV5iMC)				RA3728P5	RA3728P5	
FV M300(Elura 100/MVX 430/450/460)				RA3727P5	RA3727P5	
FV M1(Optura Xi/MVX3i)				RA3746	RA3746	
XV-1(GL1/XM1)/XV-2(GL2/XM2)		UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)	
PV130		Direct mount	Direct mount	RA3743	RA3743	

\*1:Vignetting occurs at 4:3 Still mode \*2:Vignetting occurs at Still/Video/under scanning mode \*3:Remove camera's cosmetic ring or hood before attaching the Raynox lens \*5:Vignetting occurs at Still mode \*6:Vignetting occurs at under scanning mode

Remote control function and internal video light/Flash may not work properly with conversion lens attached.

# RAYNOX Camcorder Cross Reference Table for Macro Lens

2010/9/13  
www.raynox.com

Camera Maker	Camera Model	DCR-150(4.8-diopter)	DCR-250(8-diopter)	MSN-202(25-diopter)	MSN-505(32-diopter)	DCR-5320PRO (5-diopter/3-diopter/2-diopter)	
Panasonic	HDC-SD1/DX1, AG-HSC1U	Direct mount	Direct mount	RA3743	RA3743		
	HDC-SD9/HS9/SD5/SD5EG/SX5			Direct mount	Direct mount		
	HDC-SD100/HS100			Direct mount	Direct mount		
	HDC-TM30	RA4337A+RA37305P5	RA4337A+RA37305P5	RA37305P5	RA37305P5		
	HDC-SD700/HS700(K)/TM700(K)/SDT750(K)	RA4346A	RA4346A	RA3746	RA3746		
	HDC-HS300/350/200, HDC-TM300/350, SD200	Direct mount *3	Direct mount *3	RA3743 *3	RA3743 *3		
	AG-HCK10G						
	AG-HMC150/151/155, HPX170/175					Direct mount	
	AG-DVX100(A)(AE)(AP)(BE)(BP)					Direct mount	
	AG-HVX200(E)(MC)(P), AG-HVX202EN					RA7282	
	VDR-D310	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	VDR-D400	Direct mount	Direct mount	RA3743	RA3743		
	VDR-D300/D250	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	SDR-S100/S200	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	NV-GS320	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	NV-GS500/400	Direct mount	Direct mount	RA3743	RA3743		
	NV-GS300	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	NV-GS250	Direct mount	Direct mount	RA3743	RA3743		
	VDR-M30K			RA37305P5	RA37305P5		
	NV-GS55/GS50			RA3727P5	RA3727P5		
JVC	GZ-HM400	RA4346A	RA4346A	RA3746	RA3746		
	GZ-HM550(BEK)	RA4337A	RA4337A	Direct mount	Direct mount		
	GZ-HM1(SEK)	RA4346A	RA4346A	RA3746	RA3746		
	GZ-HD620	RA4337A	RA4337A	Direct mount	Direct mount		
	GZ-HD300/HD320	RA4337A+RA37305P5	RA4337A+RA37305P5	RA37305P5	RA37305P5		
	GZ-HD40/HD30	Direct mount	Direct mount	RA3743	RA3743		
	GZ-HD5/HD6			RA3743	RA3743		
	GZ-HD3/HD7	UAC2000(Included)+RA5246	UAC2000(Included)+RA5246	UAC3500(Included)+RA5246	UAC3500(Included)+RA5246		
	GZ-MG880/MG840	RA4337A+RA37305P5	RA4337A+RA37305P5	RA37305P5	RA37305P5		
	GZ-MG275/MG255			RA37305P5	RA37305P5		
	GZ-MG575/MG555	UAC2000(Included)+RA5246	UAC2000(Included)+RA5246	UAC3500(Included)+RA5246	UAC3500(Included)+RA5246		
	GZ-MG505	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	GZ-MG77/MG67/MG70/MG50/MG40			RA37305P5	RA37305P5		
	GZ-MG47			RA37305P5	RA37305P5		
	GR-D650			RA37305P5	RA37305P5		
	GR-D350			RA3727P5	RA3727P5		
	GR-D250			RA3727P5	RA3727P5		
	GZ-MC500	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	GZ-MC200/MC100			RA37305P5	RA37305P5		
	GR-DV3000/DV3500	UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)		
	GR-DV5000	UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)		
	GR-DV900K/DV700K	UAC2000(Included)	UAC2000(Included)	UAC3500(Included)	UAC3500(Included)		
	GR-DV500	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	GR-X5	UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
	HITACHI	DZ-BD10H/10HA	Direct mount	Direct mount	RA3743	RA3743	
		DZ-BD7H/7HA/7HE, DZ-BD70/70A/70E	Direct mount	Direct mount	RA3743	RA3743	
DZ-GX3300		UAC2000(Included)+RA5237A	UAC2000(Included)+RA5237A	Direct mount	Direct mount		
DZ-GX3200				RA3734P5	RA3734P5		
TOSHIBA	DZ-GX3100			RA37305P5	RA37305P5		
	GSC-R60/R30/MEHV10			RA37305P5	RA37305P5		

\*1:Vignetting occurs at 4:3 Still mode \*2:Vignetting occurs at Still/Video/under scanning mode \*3:Remove camera's cosmetic ring or hood before attaching the Raynox lens \*5:Vignetting occurs at Still mode \*6:Vignetting occurs at under scanning mode.

Remote control function and internal video light/Flash may not work properly with conversion lens attached.