

# RAYNOX Camcorder Cross Reference Table for Telephoto Lens

Camera Maker	Camera Model	HD-2205PRO (2.2x) / HD-2200PRO-LE(2.2x)	DCR-2025PRO(2.2x)	DVR-2021(2.0x)	HDP-7700ES(3.0x)	HDP-9000EX (1.8x)	DCR-1540PRO(1.54x)	DVR-1002(0.65x+1.5x)	QC-180(1.8x)
<b>SONY</b>	HDR-FX1000(E), HVR-Z5(E)(U)					Direct mount			
	HDR-FX7(E), HVR-V1(U)(E)(N)		Direct mount			RA7262	RA5262A		
	HDR-CX7(E)(EK)(K)(KE)/CX6EK	Direct mount	RA6252(Included)+RA5237A	Direct mount			RA5237A	Direct mount	Direct mount
	HDR-UX20	RA3730(Included)			RA3730(Included)				
	HDR-UX1	RA3730(Included)		RA3730(Included)				RA3730(Included)	RA3730
	HDR-SR12(E)/SR11(E)/CX12(E)	Direct mount	RA6252(Included)+RA5237A			Direct mount		RA5237A	
	HDR-SR8(E)/SR7(E)	Direct mount	RA6252(Included)+RA5237A	Direct mount		Direct mount		RA5237A	Direct mount
	HDR-SR1	RA3730(Included)		RA3730(Included)				RA3730(Included)	RA3730
	HDR-HC3	RA3730(Included)		RA3730(Included)	RA3730(Included)			RA3730(Included)	RA3730
	HVR-Z7(E)/S270(E)					Direct mount			
	HDR-FX1, HVR-Z1(U)(E)					Direct mount			
	HDR-HC9(E)/HC7(E)/CX7/UX7(E) HDR-HC5(E)/UX5(E), HVR-HD1000	Direct mount	RA6252(Included)+RA5237A	Direct mount		Direct mount		RA5237A	Direct mount
	HDR-HC1, HVR-A1	Direct mount	RA6252(Included)+RA5237A			Direct mount		RA5237A	
	HDR-CX110/150/155E/116E/115E, HD-XR150/155E	RA3730(Included)				RA3730(Included)			
	HDR-XR100(E)/105(E)/CX100(E)/105(E)	RA3730(Included)				RA3730(Included)			
	HDR-XR500V(E)/520V(E), CX500V(E)/520V(E)	Direct mount				Direct mount			
	DCR-DVR508/DVD908(E)	Direct mount	RA6252(Included)+RA5237A	Direct mount				RA5237A	Direct mount
	DCR-DVD405/403/505	RA3730(Included)		RA3730(Included)					RA3730(Included)
	DCR-DVD308/ DVD708(E)	RA3730(Included)		RA3730(Included)					RA3730(Included)
	DCR-SR300(C)(E)	Direct mount	RA6252(Included)+RA5237A	Direct mount				RA5237A	Direct mount
	DCR-SR62(E)	RA3730(Included)		RA3730(Included)					RA3730(Included)
	DCR-SR100/SR60	RA3730(Included)		RA3730(Included)					RA3730(Included)
	DCR-HC62(E) /DVD810	RA3730(Included)				RA3730(Included)			RA3730
	DCR-HC96/90	RA3730(Included)		RA3730(Included)					RA3730(Included)
	DCR-HC48	RA3730(Included)		RA3730(Included)					RA3730(Included)
	DCR-VX2100/2000/PD-170/PD-150/DSR-250		RA6258(Included)					RA5258A	
	DCR-VX1000								
	DCR-TRV950/PDX10		RA6252(Included)+RA5237A					RA5237A	
	PMW-EX1(E)						RA7277		
	<b>Canon</b>	HF11/10/100/HG21	Direct mount			Direct mount			
HF20/21		Direct mount			Direct mount				
HF S10/11/100			RA6258(Included)						
XH G1/XH A1						Direct mount			
XL1/XL2/XL H1 16X*20X Zoom						Direct mount			
HV30/HV20/HG10		RA3743(Included)	RA6252(Included)+RA5243A		RA3743(Included)*7		RA5243B		
HV10		Direct mount		Direct mount				Direct mount	
HR10		Direct mount	RA6252(Included)+RA5237A	Direct mount	Direct mount*7		RA5237A	Direct mount	Direct mount
DM-DC40		Direct mount		Direct mount				Direct mount	Direct mount
DM-DC20		RA3727P5(Included)		RA3727P5(Included)				RA3727P5(Included)	RA3727P5
DM-FV500(ZR 100/MV 790/800/800i)		RA3728P5		RA3728P5				RA3728P5	RA3728P5
IXY DV M5(Optura 600A/MVX iE)		RA3734P5		RA3734P5				RA3734P5(Included)	Direct mount
IXY DV S1(Optura S1/MVX1Si)		RA3727P5(Included)		RA3727P5(Included)				RA3727P5(Included)	RA3727P5
IXY DV5(Elura 50/MV 6iMC)/DV3(Elura 40MC/MV5iMC)		RA3728P5		RA3728P5				RA3728P5	RA3728P5
FV M300(Elura 100/MVX 430/450/460)		RA3727P5(Included)		RA3727P5(Included)				RA3727P5(Included)	Direct mount
FV M1(Optura Xi/MVX3i)									
XV-1(GL1/XM1)/XV-2(GL2/XM2)			RA6258(Included)					RA5258A	
PV130									

\*1:Vignetting occurs at 4:3 Still mode \*2:Vignetting occurs at Still/Video/under scanning mode \*3:Remove camera's cosmetic ring or hood before attaching the Raynox lens \*5:Vignetting occurs at Still mode \*6:Vignetting occurs at under scanning mode \*7:Set the camera's f-stop at f/2.8 when used with HV20/HG10/HR10 camera.Taking an image when the camera's aperture opening of F3.4 or slower than F3.4 may increase vignetting



# RAYNOX Camcorder Cross Reference Table for Telephoto Lens

2010/2/4  
www.raynox.com

Camera Maker	Camera Model	HD-2205PRO (2.2x) / HD-2200PRO-LE(2.2x)	DCR-2025PRO(2.2x)	DVR-2021(2.0x)	HDP-7700ES(3.0x)	HDP-9000EX (1.8x)	DCR-1540PRO(1.54x)	DVR-1002(0.65x+1.5x)	QC-180(1.8x)
<b>Panasonic</b>	HDC-SD1/DX1, AG-HSC1U	RA3743(Included)			RA3743(Included)*2*3				
	HDC-SD9/HS9/SD5/SD5EG/SX5	Direct mount *3			Direct mount *3		RA5237 *3		
	HDC-SD100/HS100	Direct mount *3			Direct mount *3				
	HDC-TM30	RA37305P5(Included)			RA37305P5(Included)				
	HDC-HS300/350/200, TM300/350/SD200	RA3743(Included)	RA4343A+RA6243(Included)		RA3743(Included) *7				
	AG-HMC150/151/155, AG-HPX170/175					Direct mount			
	AG-DVX100(A)(AE)(AP)(B)(BE)(BP)					Direct mount			
	AG-HVX200(E)(MC)(P)/HVX202EN					RA7282			
	VDR-D310	Direct mount		Direct mount					Direct mount
	VDR-D400	RA3743(Included)		RA3743(Included)				RA3743(Included)	Direct mount
	VDR-D300/D250	Direct mount		Direct mount				Direct mount	Direct mount
	SDR-S100/S200	Direct mount*3		Direct mount*3				Direct mount*3	Direct mount*3
	NV-GS320	Direct mount		Direct mount					Direct mount
	NV-GS500/400	RA3743(Included)*3		RA3743(Included)*3				RA3743(Included)*3	Direct mount*3
	NV-GS300	Direct mount		Direct mount				Direct mount	Direct mount
	NV-GS250	RA3743(Included)*3		RA3743(Included)*3				RA3743(Included)*3	
VDR-M30K									
NV-GS55/GS50									
<b>JVC</b>	GZ-HM400		RA6252(Included)+RA5246						
	GZ-HD620	Direct mount			Direct mount				
	GZ-HD300/HD320	RA37305P5(Included)			RA37305P5(Included)				
	GZ-HD40/HD30	RA3743(Included)	RA6243(Included)		RA3743(Included)				
	GZ-HD5/HD6	RA3743(Included)	RA6243(Included)		RA3743(Included)				
	GZ-HD3/HD7	RA3746	RA6252(Included)+RA5246				RA5246		
	GZ-MG880/MG840	RA37305P5(Included)			RA37305P5(Included)				
	GZ-MG275/MG255	RA37305P5(Included)		RA37305P5(Included)					RA37305P5
	GZ-MG575/MG555		RA6252(Included)+RA5246				RA5246		
	GZ-MG505	Direct mount*3		Direct mount*3				Direct mount*3	Direct mount*3
	GZ-MG77/MG67/MG70/MG50/MG40	RA37305P5(Included)		RA37305P5(Included)				RA37305P5(Included)	RA37305P5
	GZ-MG47	RA37305P5(Included)		RA37305P5(Included)				RA37305P5(Included)	RA37305P5
	GR-D650	RA37305P5(Included)		RA37305P5(Included)				RA37305P5(Included)	RA37305P5
	GR-D350	RA3727P5(Included)		RA3727P5(Included)				RA3727P5(Included)	RA3727P5
	GR-D250	RA3727P5(Included)		RA3727P5(Included)				RA3727P5(Included)	RA3727P5
	GZ-MC500	Direct mount		Direct mount				Direct mount	Direct mount
	GZ-MC200/MC100	RA37305P5(Included)		RA37305P5(Included)				RA37305P5(Included)	RA37305P5
	GR-DV3000/DV3500								
	GR-DV5000								
	GR-DV900K/DV700K								
GR-DV500									
GR-X5									
<b>HITACHI</b>	DZ-BD10H/10HA	RA3743(Included)	RA6243(Included)		RA3743(Included)*5		RA5243B		
	DZ-BD7(H)(HA)(HE), DZ-BD70(A)(E)	RA3743(Included)*5		RA3743(Included)*5	RA3743(Included)*5			RA3743(Included)*5	
	DZ-GX3300	Direct mount		Direct mount				Direct mount	Direct mount
	DZ-GX3200	RA3734P5*3		RA3734P5*3				RA3734P5(Included)*3	Direct mount*3
	DZ-GX3100	RA37305P5(Included)		RA37305P5(Included)				RA37305P5(Included)	RA37305P5
<b>TOSHIBA</b>	GSC-R60/R30/MEHV10	RA37305P5(Included)		RA37305P5(Included)				RA37305P5(Included)	RA37305P5

\*1:Vignetting occurs at 4:3 Still mode \*2:Vignetting occurs at Still/Video/under scanning mode \*3:Remove camera's cosmetic ring or hood before attaching the Raynox lens \*5:Vignetting occurs at Still mode \*6:Vignetting occurs at under scanning mode \*7:Set the camera's f-stop at f/2.8 when used with HV20/HG10/HR10 camera.Taking an image when the camera's aperture opening of F3.4 or slower than F3.4 may increase vignetting

Remote control function and internal video light/Flash may not work properly with conversion lens attached.